## **Audvance extension board**

This board is designed for Telefunken M15A machines to:

- facilitate easy adjustment of the bias trimmer level on the record board.
- do measurements on any component or pin on both playback and record boards.
- facilitate a direct output of the playback head to feed to any type of external playback amplifier.

The direct output of the playback head is available on the front of the extension board when it is inserted in place of a BC-WV1 playback board. There are three pins, WKA, WKB and GND. For a balanced connection to some external playback amplifier WKA and WKB can be considered as plus and minus signals (or the other way around for inverted phase). No one can tell what the correct phase is, so in my view it does not really matter. GND can be connected to the shield of this balanced cable.